

USB Download Instructions

IMPORTANT: OVEN CANNOT BE IN COOK MODE WHEN PERFORMING THIS PROCEDURE

1. Turn on your oven but do not push Start
2. Plug in your flash drive to the USB port. **NOTE: The flash drive must be one that is formatted to FAT file system**
3. Press the USB DATA button and the display will read “writing USB file”.
4. The display will read “file saved press ok” when done.
5. After pressing ok It will then ask “clear log? no”
6. Press the UP or DOWN arrow to answer Yes or No.
7. Press OK
8. Your oven temperature history is now saved as a CSV file.
9. Call customer service if you have any questions (800) 423-0698